



Display Accessories

Live. Dare. Create.



Airbrush Pen



Art Pen



Grip Pen



Pro Pen

Standard Nibs



Felt Nibs



Flex Nibs



Wacom Pro Pen 2



Wacom Pro Pen Slim



Wacom Pro Pen 3D



Pro Pen 2 Standard Nibs



Pro Pen 2 Felt Nibs



Wacom Adjustable Stand
(For Wacom Cintiq 16)



Wacom Stand
(for Wacom Cintiq Pro 13 & 16)



Wacom Stand
(for Wacom MobileStudio Pro)



Wacom Flex Arm
(for Wacom Cintiq Pro 24 & 32)



Tilt Stand
(for Cintiq 22)



Cintiq Ergo Stand
(for Cintiq 27)



Ergo Stand
(for Wacom Cintiq Pro 24)



Ergo Stand
(for Wacom Cintiq Pro 32)



Wacom VESA Mount
(for Wacom Cintiq Pro 24 & 32 with
3rd party VESA display arms)



Soft Case
(Medium & Large)



ExpressKey Remote



Wacom Wireless Keyboard



Wacom Link



Wacom Link Plus



Wacom Color Manager



Case for Wacom Pro Pens



Pro Accessory Kit





Wacom®		Cintiq		Wacom Cintiq	Wacom Cintiq Pro				Wacom MobileStudio Pro	
		DTK-2200 DTH-2200	DTK-2700 DTH-2700	DTK1660	DTH-1320	DTH-1620	DTK-2420 DTH-2420	DTH-3220	DTH-W1320	DTH-W1620
Display Accessories		Part Numbers								
Pens & Nibs	Airbrush Pen (2048 pressure levels)	KP-400E-01	X	X	X	X	X	X	X	X
	Art Pen (2048 pressure levels)	KP-701E-01	X	X	X	X	X	X	X	X
	Wacom Grip Pen (2048 pressure levels)	KP-501E-01	*	X	X	X	X	X	X	X
	Wacom Pro Pen (2048 pressure levels)	KP-503E	X	*	X	X	X	X	X	X
	Standard Pen Nibs (5 pack)	ACK-20001	X	X						
	Hard Felt Pen Nibs (5 pack)	ACK-20003	X	X						
	Flex Pen Nibs (5 pack)	ACK-20004	X	X						
	Wacom Pro Pen 2 (8192 pressure levels)	KP504E			*	*	*	*	*	*
	Wacom Pro Pen Slim (8192 pressure levels)	KP301E00DZ			X	X	X	X	X	X
	Wacom Pro Pen 3D (8192 pressure levels)	KP505			X	X	X	X	X	X
Stands	Wacom Pro Pen 2 Standard Nibs (10 pack)	ACK22211			X	X	X	X	X	X
	Wacom Pro Pen 2 Felt Nibs (10 pack)	ACK22213				X	X	X	X	X
	Wacom Adjustable Stand for Cintiq 16	ACK620K			X					
	Cintiq 22 Tilt Stand	MST-A170	X							
	Cintiq Ergo Stand	ACK411040Z		X						
	Wacom Cintiq Pro 13 & 16 Adjustable Stand	ACK62701K				X	X			
	Wacom Cintiq Pro 24 Ergo Stand	ACK62801						X		
	Wacom Cintiq Pro 32 Ergo Stand	ACK62802							X	
	Wacom Flex Arm	ACK62803K						X	X	
	Wacom VESA Mount (For 3rd party VESA display arms)	ACK62804K						X	X	
Cases	Wacom MobileStudio Pro Stand	ACK627K							X	X
	Soft Case, medium	ACK52701				X			X	
	Soft Case, large	ACK52702			X		X			X
	Pro Accessory Kit	ACK-40001	X							
Miscellaneous	Case for Pro Pens	ACK42215			X	*	*	*	*	*
	ExpressKey Remote	ACK-411050	X	*	X	X	X	*	*	X
	Wacom Color Manager	EODIS3-DCWA	X	X	X	X	X	X	X	X
	Wireless Keyboard	WKT-400	X	X	X	X	X	X	X	X
	Wacom Link	ACK42719							X	X
	Wacom Link Plus	ACK42819				X	X			

Legend: X = Optional Accessory, * = Replacement Part (Included in box with main product) Note: This is a list of the most commonly purchased accessories and replacement parts. It is not a comprehensive list.